




Tip of the Week

Ramp Timer PRO

How to save custom lighting programs

[The Ramp Timer PRO features four memory locations M1, M2, M3, and M4]

- 1 Choose M1, M2, M3, or M4. Press and hold for 2 seconds. The display screen will read SL-1, SL-2, SL-3, or SL-4 respectively.



- 2 Enter your custom settings for both Channels (CH1 and CH2) by using the plus/minus buttons.



- 3 Press the same memory key location (M1, M2, M3, or M4) and hold for 5 seconds. The display screen will read SF-1, SF-2, SF-3, or SF-4 respectively.



- 4 Your program is now saved in your selected memory location.

Note: Whenever you have used an on-demand effect (such as Storm) or temporarily adjusted a color spectrum and want the timer to go back into its normal timing schedule *press* RESUME. Once you press RESUME, the current time of day will appear on the Ramp Timer PRO and the controller is in your programmed light cycle.